


Operating Instructions  
Incl. Declaration of Conformity


## Compact Pirani Capacitance Gauge PCR 260




BG 805 180 BE / C (2006-05)

### Product Identification

In all communications with Pfeiffer Vacuum, please specify the information given on the product nameplate. For convenient reference copy that information into the diagram below.

Pfeiffer Vacuum, D-35614 Aslar  
 Typ: \_\_\_\_\_  
 No: \_\_\_\_\_  
 F-No: \_\_\_\_\_  
 \_\_\_\_\_ V \_\_\_\_\_ W 



### Validity

This document applies to products with the following part numbers:

PT R26 850 (DN 16 ISO-KF)  
PT R26 851 (DN 16 CF-F)

The part number (No) can be taken from the product nameplate.

If not indicated otherwise in the legends, the illustrations in this document correspond to DN 16 ISO-KF vacuum connection. They apply to other vacuum connections by analogy.

We reserve the right to make technical changes without prior notice.

All dimensions are indicated in mm.

### Intended Use

The Compact Pirani Capacitance Gauge PCR 260 has been designed for vacuum measurement of gases in the pressure range of  $5 \times 10^{-4}$  ... 1500 mbar.

It must not be used for measuring flammable or combustible gases which react in air.

The gauge can be operated in connection with a Pfeiffer Vacuum controller or with another evaluation unit.



### Functional Principle

The PCR gauge is a combination gauge consisting of a Pirani sensor and a capacitive diaphragm sensor. Both sensors are constantly active.


At low pressures, only the signal of the Pirani sensor is used for pressure measurement; at high pressures, only the signal of the capacitive diaphragm sensor. To determine the output signal in the intermediate range, both signals are used proportional to the pressure.

### Safety

#### Symbols Used



### Personnel Qualifications



### General Safety Instructions

- Adhere to the applicable regulations and take the necessary precautions for the process media used. Consider possible reactions between the product materials and the process media. Consider possible reactions of the process media due to the heat generated by the product.
- Adhere to the applicable regulations (e.g. explosion) and take the necessary precautions for all work you are going to do and consider the safety instructions in this document.
- Before beginning to work, find out whether any vacuum components are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.

Communicate the safety instructions to all other users.

### Liability and Warranty

Pfeiffer Vacuum assumes no liability and the warranty becomes null and void if the end-user or third parties

- disregard the information in this document
- use the product in a non-conforming manner
- make any kind of changes (modifications, alterations etc.) to the product
- use the product with accessories not listed in the product documentation.

The end-user assumes the responsibility in conjunction with the process media used.

Gauge failures due to contamination, as well as expendable parts (filament), are not covered by the warranty.



### Technical Data

Measurement principle	100 mbar <sup>1)</sup> ... 1500 mbar	capacitance diaphragm sensor
	$5 \times 10^{-4}$ ... 1 mbar	thermal conductance according to Pirani crossover range
	1 ... 100 mbar <sup>1)</sup>	
Measurement range (air, O <sub>2</sub> , CO, N <sub>2</sub> )		$5 \times 10^{-4}$ ... 1500 mbar
Accuracy (N <sub>2</sub> )		
	$1 \times 10^{-3}$ ... 50 mbar	±15% of reading
	50 ... 950 mbar	±5% of reading
	Atmospheric pressure (950 ... 1050 mbar)	±2.5% of reading
Repeatability (N <sub>2</sub> )		±2% of reading (1x10 <sup>-3</sup> ... 1100 mbar)


Output signal (measurement signal)		
Voltage range		0 ... +9.0 V
Mesasurement range		+2.2 ... +8.68 V
Voltage vs. pressure		1 V/decade, logarithmic

Output impedance		2 x 4.7 Ω, short circuit-proof
Minimum load impedance		10 kΩ
Response time		10 ms

Gauge identification		resistor 3 kΩ between pin 1 and pin 5 of electrical connector (→ "Electrical Connection")
----------------------	--	---

HV Adjustment		at $<< 10^{-4}$ mbar (with potentiometer <HV>)
---------------	--	--

### Supply



Supply voltage at gauge		+15 ... +30 VDC (ripple ≤ 1 V <sub>pp</sub> )
Power consumption		≤ 2.5 W
Fuse to be connected		1 AT

Electrical connection		Hirschmann connector type GO 6, 6 pin, male
Sensor cable		5 poles plus shielding
Cable length		≤ 150 m (5x0.25 mm <sup>2</sup> ) ≤ 200 m (5x0.34 mm <sup>2</sup> )

Grounding concept		(→ "Electrical Connection")
Vacuum connection to signal ground		connected via 1 MΩ

Materials exposed to vacuum		
Vacuum connection		stainless steel
Pirani filament		tungsten
Feedthrough		glass
Orifice		stainless steel
Other materials		Ni, Cu, NiFe, SnAg, glass, Al <sub>2</sub> O <sub>3</sub> (>99.5%), AgPd

Internal volume		
DN 16 ISO-KF		≈ 6 cm <sup>3</sup>
DN 16 CF-F		≈ 8 cm <sup>3</sup>
Admissible pressure		≤ 5 bar (absolute)

Admissible Temperatures		
Storage		-20 ... +65 °C
Operation (ambient)		+10 ... +50 °C
Bake-out <sup>2)</sup>		≤ 80 °C
Filament temperature		< 160 °C


Relative humidity		≤ 80% at temperatures ≤ +31 °C, decreasing to 50% at +40 °C
-------------------	--	---

Mounting orientation		any
Use		indoors only altitudes up to 2000 m NN

Protection category		IP 40
---------------------	--	-------

<sup>1)</sup> Crossover range for air, O<sub>2</sub>, CO and N<sub>2</sub> 10 mbar, 100 mbar in heavy gases.  
<sup>2)</sup> Temperature at vacuum connection with horizontal mounting orientation. During bake-out, measurement range, accuracy, and repeatability may deviate from specifications.


### Dimensions [mm]



Weight	
DN 16 ISO-KF	90 g
DN 16 CF-F	120 g

### Output Signal vs. Pressure

Pressure p [mbar]



$$p = 10^{(U-c)} \Leftrightarrow U = c + \log_{10} p$$


valid in the range  $5 \times 10^{-4}$  mbar < p < 1500 mbar

U	p	c	U	p	c
[V]	[mbar]	5.5	[V]	[micron]	2.625
[V]	[ubar]	2.5	[V]	[Pa]	3.5
[V]	[Torr]	5.625	[V]	[kPa]	6.5
[V]	[mTorr]	2.625			

where p pressure  
U output signal  
c constant (pressure unit dependent)

### Gas Type Dependence

Indicated pressure (gauge calibrated for air)



### Calibration factors

valid for Pirani pressure range below 1 mbar

$$p_{\text{eff}} = C \times \text{indicated pressure}$$

Gas type	Calibration factor C	Gas type	Calibration factor C
He	0.8	H <sub>2</sub>	0.5
Ne	1.4	air, O <sub>2</sub> , CO, N <sub>2</sub>	1.0
Ar	1.7	CO <sub>2</sub>	0.9
Kr	2.4	water vapour	0.5
Xe	3.0	Freon 12	0.7

### Installation

#### Vacuum Connection



**STOP DANGER**

Caution: overpressure in the vacuum system >1 bar

Injury caused by released parts and harm caused by escaping process gases can result if clamps are opened while the vacuum system is pressurized.

Do not open any clamps while the vacuum system is pressurized. Use the type of clamps which are suited to overpressure.



**STOP DANGER**

Caution: overpressure in the vacuum system >2.5 bar

KF flange connections with elastomer seals (e.g. O-rings) cannot withstand such pressures. Process media can thus leak and possibly damage your health.

Use O-rings provided with an outer centering ring.



**STOP DANGER**

Caution: protective ground

Incorrectly grounded products can be extremely hazardous in the event of a fault.

The gauge must be electrically connected to the grounded vacuum chamber. This connection must conform to the requirements of a protective connection according to EN 61010:

- CF connections fulfill this requirement
- For gauges with a KF connection, use a conductive metallic clamping ring.

**! Caution**



Caution: vacuum component  
Dirt and damages impair the function of the vacuum component.  
When handling vacuum components, take appropriate measures to ensure cleanliness and prevent damages.

**! Caution**




Caution: dirt sensitive area  
Touching the product or parts thereof with one's bare hands increases the desorption rate.  
Always wear clean, lint-free gloves and use clean tools when working in this area.



The gauge may be mounted in any orientation. To keep condensates and particles from getting into the measuring chamber preferably choose a horizontal to upright position and possibly use a seal with a centering ring and filter. If adjustment should be possible after the gauge has been installed, be sure to install it so that the potentiometer can be accessed (→ "Adjustment").

Remove the protective lid and install the product at the vacuum system.




Keep the protective lid





898051806010

(2006-05)


## Electrical Connection

 Make sure the vacuum connection is properly made (→ "Vacuum Connection").


**1** If no sensor cable is available, make one according to the following diagram.



Electrical connection  
 Pin 1 Identification  
 Pin 2 Signal output  
 Pin 3 Signal common  
 Pin 4 Supply  
 Pin 5 Supply common (GND)  
 Pin 6 Screen



**2** Connect the sensor cable to the gauge and the controller or PLC and secure it with the locking screw.



## Operation

When the supply voltage is being applied, the measurement signal is available at the connector (→ "Electrical Connection").



Allow a stabilization period of ≈10 minutes after power has been applied.

It is advisable to operate the gauge continuously, irrespective of the pressure.

## Gas Type Dependence

Pressure Range	Measurement Principle	Gas Type Dependence
100 <sup>1)</sup> ... 1500 mbar	capacitance diaphragm sensor	independent of gas type, no correction required
1 ... 100 <sup>1)</sup> mbar	capacitance diaphragm sensor and Pirani sensor	crossover range
5×10 <sup>-4</sup> ... 1 mbar	Pirani sensor	proportional to pressure <sup>3)</sup>

## Adjustment

The gauge is factory calibrated. Due to long time operation or contamination, a zero drift could occur. Periodically check the zero and adjust it if necessary.

The zero must be adjusted at the ambient temperature at which the gauge is normally operated.

**1** If you are using a seal with centering ring and filter, check that they are clean or replace them if necessary (→ "Deinstallation").

**2** Activate the gauge.


**3** Connect a DC voltmeter to output signal (→ "Electrical Connection").


**4** Evacuate vacuum system to  $p << 10^{-4}$  mbar.



Wait at least 2 minutes.

**5** Carry out adjustment with potentiometer <HV> by means of the enclosed screwdriver.



 PCR 260 gauges do not require adjustment at atmospheric pressure.

## Deinstallation

 **DANGER**



Caution: contaminated parts

Contaminated parts can be detrimental to health and environment.

Before beginning to work, find out whether any parts are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.

 **Caution**



Caution: vacuum component

Dirt and damages impair the function of the vacuum component.

When handling vacuum components, take appropriate measures to ensure cleanliness and prevent damages.

 **Caution**



Caution: dirt sensitive area


Touching the product or parts thereof with one's bare hands increases the desorption rate.

Always wear clean, lint-free gloves and use clean tools when working in this area.

**1** Vent vacuum system.

**2** Turn the gauge off.


**3** Loosen locking screw of sensor cable connector and unplug sensor cable.



**4** Remove the gauge from the vacuum system and cover the vacuum connection with the protective lid.

<sup>3)</sup> The pressure reading applies to dry air, O<sub>2</sub>, CO and N<sub>2</sub>. For other gases, it has to be converted (calibration factors → "Technical Data").

## Maintenance, Repair


 Gauge failures due to contamination, as well as expendable parts (filament), are not covered by the warranty.

The product requires no maintenance.


## Accessories

	Part number
Centering ring DN 16 ISO-KF with fine filter	PT 120 132-T

## Returning the Product




**WARNING**


 Caution: forwarding contaminated products  
Contaminated products (e.g. radioactive, toxic, caustic or microbiological hazard) can be detrimental to health and environment.  
Products returned to INFICON should preferably be free of harmful substances. Adhere to the forwarding regulations of all involved countries and forwarding companies and enclose a duly completed declaration of contamination


Products that are not clearly declared as "free of harmful substances" are decontaminated at the expense of the customer. Products not accompanied by a duly completed declaration of contamination are returned to the sender at his own expense.

## Disposal




**DANGER**

 Caution: contaminated parts  
Contaminated parts can be detrimental to health and environment.  
Before beginning to work, find out whether any parts are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.



**WARNING**

 Caution: substances detrimental to the environment  
Products or parts thereof (mechanical and electric components, operating fluids etc.) can be detrimental to the environment.  
Dispose of such substances in accordance with the relevant local regulations.


## Separating the components


After disassembling the product, separate its components according to the following criteria:

- Contaminated components  
Contaminated components (radioactive, toxic, caustic, or biological hazard etc.) must be decontaminated in accordance with the relevant national regulations, separated according to their materials, and disposed of.
- Other components  
Such components must be separated according to their materials and recycled.

## Declaration of Contamination

The service, repair, and/or disposal of vacuum equipment and components will only be carried out if a correctly completed declaration has been submitted. Non-completion will result in delay. This declaration may only be completed (in block letters) and signed by authorized and qualified staff.

- 1 **Description of product**  
Type \_\_\_\_\_  
Part number \_\_\_\_\_  
Serial number \_\_\_\_\_
- 2 **Reason for return**  
\_\_\_\_\_
- 3 **Operating fluid(s) used**  
(Must be drained before shipping.)  
\_\_\_\_\_
- 4 **Used in copper process**  
no  yes   Seal product in plastic bag and mark it with a corresponding label.
- 5 **Process related contamination of product:**

toxic no <input type="checkbox"/> 1) yes <input type="checkbox"/> corrosive no <input type="checkbox"/> 1) yes <input type="checkbox"/> biological hazard no <input type="checkbox"/> yes <input type="checkbox"/> 2) explosive no <input type="checkbox"/> yes <input type="checkbox"/> 2) radioactive no <input type="checkbox"/> yes <input type="checkbox"/> 2) other harmful substances no <input type="checkbox"/> 1) yes <input type="checkbox"/>	
---	--

1) or not containing any amount of hazardous residues that exceed the permissible exposure limits  
yes

2) Products thus contaminated will not be accepted without written evidence of decontamination.
- 6 **Harmful substances, gases and/or by-products**  
Please list all substances, gases, and by-products which the product may have come into contact with:  

Trade/product name manufacturer	Chemical name (or symbol)

Precautions associated with substance	Action if human contact
- 7 **Legally binding declaration:**  
We hereby declare that the information on this form is complete and accurate and that we will assume any further costs that may arise. The contaminated product will be dispatched in accordance with the applicable regulations.  
 Organization/company \_\_\_\_\_  
 Address \_\_\_\_\_  
 Post code, place \_\_\_\_\_  
 Phone \_\_\_\_\_ Fax \_\_\_\_\_  
 Email \_\_\_\_\_  
 Name \_\_\_\_\_  
 Company stamp \_\_\_\_\_

This form can be downloaded from our website.  
Copies: Original for addressee  
1 copy for accompanying documents  
1 copy for file of sender

## Declaration of Conformity



We, Pfeiffer Vacuum, hereby declare that the equipment mentioned below complies with the provisions of the Directive relating to electrical equipment designed for use within certain voltage limits 73/23/EEC and the Directive relating to electromagnetic compatibility 89/336/EEC.

**Compact Pirani Capacitance  
Gauge  
PCR 260**

### Part numbers

PT R26 850  
PT R26 851

### Standards

Harmonized and international/national standards and specifications:

- EN 61010-1 (Safety requirements for electrical equipment for measurement, control and laboratory use)
- EN 61000-6-2 (Electromagnetic compatibility generic immunity standard)
- EN 61000-6-3 (Electromagnetic compatibility generic emission standard)

### Signatures

Pfeiffer Vacuum GmbH, Asslar

19 May 2006

Wolfgang Dondorf  
Managing director

**PFEIFFER**  **VACUUM**

Berliner Strasse 43  
D-35614 Asslar  
Deutschland  
Tel +49 (0) 6441 802-0  
Fax +49 (0) 6441 802-202  
info@pfeiffer-vacuum.de  
www.pfeiffer-vacuum.net